

DVD Player Owner's Manual



**Black and Silver Bezels*

Welcome to the Digital Video Revolution!

Your Cyber Home DVD Player is designed to provide a great Home Theater experience with super-crisp Video and thundering Digital Sound. Please retain this User Manual for future reference. Remember to read the manual carefully before connecting and powering on the unit.



Important Safety Precautions

WARNING:

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR ANNOYING INTERFERENCE, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE AND ONLY USE THE RECOMMENDED ACCESSORIES.

CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL FOR SERVICING.



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of not isolated dangerous voltage within the inside of the product that may be sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and servicing instructions in the literature accompanying the appliance.

**CLASS 1 LASER
PRODUCT**

The DVD-Player is a class 1 laser product. However, this DVD-Player uses a visible laser beam, which could cause hazardous radiation exposure, if directed. Be sure to operate the DVD-Player correctly as instructed. When this DVD-Player is plugged into the plug socket, do not place your eyes close to the opening of the disc tray and other openings to look into the inside of this player. Do not open covers and do not repair yourself. Refer to the qualified personnel for servicing. Invisible laser radiation when cover is opened and interlock failed or defeated. Avoid direct exposure to beam.

When using this DVD player, basic precautions should always be followed, including the following:

- Read these instructions
- Keep these instructions
- Heed all warnings
- Follow all instructions
- Do not use this apparatus near water
- Clean only with dry cloth
- Do not block any ventilation opening. Install in accordance with the manufacture's instructions
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defect the safety purpose of the polarized plug. A polarized plug has two blades with one wider than other. The wide blade is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments / accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over.



- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged liquid has been spilled or objects have fallen into apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Power cord protection:

To avoid any malfunctions of the unit and to protect against electric Shock, fire or personal injury, please observe the following:

- Hold the plug firmly when connecting or disconnecting the AC power cord to this unit.
- Do not connect or disconnect the AC power cord with wet hands.
- Keep the AC power cord away from heating appliances.

- Never put any heavy object on the AC power cord.
- Do not attempt to repair or reconstruct the AC power cord in any way.
- Remove dust, dirt, etc. on the plug at regular intervals.
- If the unit has been dropped or otherwise damaged, turn off the power and disconnect the AC power cord.
- If smoke, odors or noises are emitted from the unit, turn off the power and disconnect the AC power cord.

Placement:

Avoid placing the unit in areas of:

- direct sunlight, heating radiators or closed automobiles
- high temperature [over 35° C (95° F)] or high humidity (over 90%)
- excessive dust
- vibration, impact or where the surface is tilted, as the internal parts may be seriously damaged

Non-use periods:

- When the unit is not used, turn the power off.
- When the unit is unused for a long period of time, the unit should be unplugged from the household AC outlet.

No fingers or other objects inside:

- Touching internal parts of this unit is dangerous and may cause serious damage to the unit. Do not attempt to disassemble the unit.
- Do not put any foreign object on the disc tray.

Keep away from water and magnets:

- Keep the unit away from flower vases, tubs, sinks, etc. If liquids are spilled into the unit, serious damage could occur.
- Keep magnetic objects, such as speakers, distant from the player.

Stacking:

- Place the unit in a horizontal position and do not place anything heavy on it.
- Do not place the unit on amplifiers or other equipment, which may become hot

Condensation:

Moisture may form on the lens in the following cases:

- immediately after a heater has been turned on
- in a steamy or very humid room
- the unit is moved from a cold environment to a warm one

If moisture forms inside this unit, it may not operate properly. In this case, turn off the power and wait about one hour for the moisture to evaporate.

Noise interference while a broadcast is being received:

Depending on the reception condition of the TV, interference may appear on the TV screen while you are watching a TV broadcast, if the unit is switched on. This is not a malfunction of the unit or the TV. To watch a TV broadcast, turn off this unit.

SAVE THESE INSTRUCTIONS

Table of Contents

General Information

Safety Precautions	2
Table of Contents	3
DVD Player Features & Supported Discs	4
Caring for Optical Discs	5

Player Layout, Controls and Functions

Preparing and Using the Remote Control	6
Remote Control Functions	7
DVD Front Panel Functions	9
DVD Display Functions	10
Dimming the Front VFD Display	10
Back Panel Connectors	11

Connecting the DVD Player to your TV

Typical Connection - Composite Video & Stereo Audio	12
S-Video & Stereo Audio Connections	13
Digital Audio Connections	13
Component Video Connections	14

Basic Playback Functions

Getting Started - Powering On & Playing a Disc	15
Stopping and Pausing Play	16
Navigating Disc Menus	17

Advanced Playback Functions

Fast Forward/Reverse & Slow Motion Scanning	18
Skip Forward and Skip Back	18
Jumping to a Specific Chapter/Track or Time Position	19
Previewing Titles, Chapters or Tracks Before Playback	20
Saving Locations for Quick Play with Bookmarks	21
Repeating a Title, Chapter/Track or Disc	22
Repeating a Specific Time Segment	22
Playing Tracks in a Particular Order with Program Play	23
Playing MP3 Files with the MP3 Navigator	24
Viewing JPG Picture Files on your TV	25
Using the Zoom Function	26
More Audio & Video Functions	27

Setting Player Options

Using the On-Screen Setup Menu	28
Parental Lock and General Options	29

Adjusting Audio and Video Settings

Audio Setup Options	30
Video Setup Options	31
Language Options	32

Further Information

Troubleshooting Common Problems	33
Specifications	34
Glossary of DVD-related Terms	35
Index	37

DVD Player Features & Supported Discs

Welcome to the Digital Video Revolution! Your new DVD Player opens the door to a much richer home entertainment experience than you've ever seen before. Enhanced Video and Sound quality, as well as greater flexibility and options are just some of the benefits of Digital Video over conventional formats such as VHS. And your DVD Player also doubles as a superior Music machine, playing CD Audio or "Compact" Discs, as well as discs containing MP3 Music Files.

Features

- Suitable for multiple disc formats, including DVD, Video CD (versions 1.1 and 2.0), conventional Audio CD's, CD-R/RW, MP3 and DTS.
- Multiple levels of slow playback. Slow motion without distracting signals in various speeds.
- Repeat playback - Video segments can be selected for repeat playback.
- Multi-Language Display - Usage mode can be displayed on the screen in different languages.
- On-Screen Display and Setup - On-Screen Interface for MP3 Playback.
- Parental Control allows you to block discs with a password depending on the rating.
- Standby Power with LED for quick power-on and power save.
- View JPG Images on your TV.
- Screen Saver protects your TV when unit is paused for a length of time.
- Zoom In and Zoom Out on picture in still mode or playback mode.
- Program Function - Specify the playback sequence for MP3, Audio CD or DVD Tracks.
- Component, S-Video & Composite Video Outputs.
- Coaxial Digital & Stereo Analog Audio Output.
- Multi-functional remote control - A wide variety of functions can be controlled by the Remote Control in the most convenient way.
- Direct track selection function (MP3 and CD) - Number buttons can be used for quick selection of MP3 and CD titles with the remote control.

Supported Disc Formats

The following is a list of disc types that are suitable for play in your DVD Player:



Digital Video Discs

This player is suitable for DVDs of 12cm and 8cm sizes. Single-Sided and Double-Sided DVDs of Single-Layer or Double-Layer type are supported. Discs of NTSC and PAL color systems are supported.

Note: This DVD Player adheres to Region Code Standards. Units sold in North America will only play Region Code 1 discs. The region code is marked on the disc as shown:



Video CDs

This player supports Video CDs with or without the PBC function. PBC allows for more advanced navigation and features.



Compact Discs - Digital Audio

Music CDs may be used in this player. Also, CD-R and CD-RW discs containing CD-Audio tracks are supported.



MP3 Discs (Including CD-R & CD-RW)

This player features an On-Screen MP3 Player for navigating and playing MP3 files stored on disc. Files must have the ".MP3" extension. When recording MP3 files to a CD-R or CD-RW disc, you must "close the session" before the disc will be useable with this player. A maximum of 250 directories and tracks are allowed.



JPG Image Files (CD-R & CD-RW)

The On-Screen JPG Navigator lets you select images to view on your TV. Slide-Show mode is also supported. Files must be saved with the ".JPG" extension.

*Specifications are subject to change without notice. *All trademarks, logos, brand names and company names are the property of their respective owners.

Caring for Optical Discs

Handling of Discs:

Please hold the disc by gripping the rim or by placing the index finger in the central hole. Never touch the signal surface, which is shiny. This applies to both sides of double sided discs.

Cleaning of Discs:

Finger prints or stains on the surface of the disc may cause signal loss. Depending on the degree of the stain, the reflected luminosity from the signal surface may be weakened, resulting in degraded picture quality. Therefore, please use a soft cloth and wipe in a radiating manner from the center of the disc to the outer rims when cleaning the disc surface.

If the surface of your disc is very dirty, please wipe the disc with a moist cloth, followed by a dry soft cloth to remove all water stains.

Never use electrostatic prevention products or solutions which contain benzene, thinner or any other vaporizing substances, as they may damage the disc surface.

Never add labels or adhesive tapes on the discs and be careful not to scratch or damage the disc surface.

Storage of Discs:

To prevent discs from becoming bent or deformed, they should be vertically kept in the disc storage case. To prevent damage, avoid leaving discs in your car, where they may be subject to direct sunlight and high temperature.




Please thoroughly read the "Instruction Points for Attention" on the discs.

Cleaning the DVD Player:

The control panel and the case of the player will only require occasional wiping with a soft cloth. Areas with stubborn stains can be cleaned with a soft cloth dipped in a neutral detergent. To prevent damaging the player, never use vaporizing solutions.

Disc Accessories:

Do not use any disc accessory to improve the audio quality, disc protective solutions or lens cleaner. These products may cause problems.




Preparing and Using the Remote Control

Installing the Batteries

If the remote control only operates when you get closer to the DVD Player, it may mean the batteries are weak. Please replace the two batteries simultaneously with two new batteries (Size AAA, R03, 1.5V) of the same type. Please note the positive (+) and negative (-) polarity shown inside the battery compartment on the remote.

1. Push down and then outwards to remove the battery compartment cover.
2. Insert Batteries following polarity marked inside compartment.
3. Slide Cover back into place.




Important Note about Batteries

- When changing batteries, it is not recommended to use a mix old and new batteries or batteries of different brands simultaneously.
- If the unit will not be used for an extended length of time, it's wise to remove the batteries before storage.
- The life of the batteries depends on the amount of usage. With typical use, a battery life of approximately 6 months can be expected.

Operation of Remote Control

When using the control, please aim at the device's remote control sensor, located in the DVD Player's Display area. A 30 degree angle is recommended for best operation.




Quick Tips

- Make sure no objects are between the remote and the player.
- Similar remote controls could interfere with the function of the player.
- Make sure not to store the remote upside down or with any objects pressing on the buttons - this could drain the battery.

Remote Control Functions (1 of 2)

Understanding the Buttons on the Remote

The Remote Control provides access to the DVD Player's advanced functions, such as searching, repeating video segments, accessing the Setup Menu, choosing subtitle mode, muting the volume and pausing the action, just to name a few. The remote is also used to put the unit into "standby" mode, and power it on again. If the remote is missing, you'll need to use the front panel switch to turn the unit off, then back on to exit Standby Mode.




*See next page for remaining buttons.


Remote Control Functions (2 of 2)

.....

*See previous page for upper buttons.



DVD Front Panel Functions




Quick Tips

- When the unit is powered off by the Remote Control, it will be in standby mode.
- If the Remote Control is not handy, you can bring the unit out of Standby Mode by pressing the Play / Pause or Open / Close buttons on the front bezel.

DVD Display Functions

Display Functions

The DVD Player Display shows current operation, disc type, elapsed playback time and other useful information. Some functions require specific disc formats or features.



Dimming the Front VFD Display


Adjusting the Brightness of the Front Display

With NO DISC in the unit and "INSERT DISC" shown on the Display, the DISPLAY button functions as a 4-phase Dimmer for the DVD Player's front VFD (Vacuum Fluorescent Display).



Eject and remove the Current Disc


Press the Open / Close ▲ button on the player to eject the disc tray. Remove the disc and push the button to return the disc tray back into the unit.



Press the DISPLAY Button

Press the DISPLAY button repeatedly to cycle through the four brightness levels.


INSERT DISC INSERT DISC
INSERT DISC INSERT DISC



Back Panel Connectors

Connections on the Back Panel

The back panel is where you'll find all the physical connections for the DVD Player. You will only use one Video and one Audio connection at any given time. For instance, if you're using the Composite Video jack to connect to your TV, the S-Video and Component connectors will be unused.




Connecting the DVD Player to your TV / Receiver

Determining the Video & Audio Connections You Will Use

The first step to using your new DVD Player is to make the cable connections that will allow you to see the video and hear the audio on your TV and optional Stereo or Digital Receiver. Your DVD Player has multiple Video and Audio outputs. Generally, you will only use one Video and one Audio output and any one time. The type of outputs you use will be determined by the capabilities of your Television or receiver. It is recommended that you use the highest quality output that your TV or receiver will support.


Television Connections (One Required)

In order to use your DVD Player, your TV must support at least one of the Video Input types shown below. To get started, identify the best Video Connection shown below that your TV offers and proceed to that section. If you are using your TV's speakers for audio, rather than a separate receiver or amplifier, you will use the Stereo Audio In, outlined in sections 1 and 2.



Receiver Connection (Optional)

To take advantage of 5.1 Channel Dolby Surround Sound or Digital Theater System (DTS), you'll need a receiver and a Speaker System with five speakers plus a sub-woofer. Your receiver must be equipped with a CoAxial Digital Audio In Jack.




Typical Connection - Composite Video & Stereo Audio

1 Typical Connection - Connecting to a TV with Composite Video In and Stereo Audio In

If your TV has only a single Video Input jack, typically a yellow-colored plug, you will use the Composite Video output of the DVD Player for the Video Connection. We'll also assume your TV has Red and White Stereo Audio In connectors. You will use these for the Audio Connection.



- Use the included Video Cable (Yellow) to connect the Video Out of the DVD Player to the Video In of your TV.
- Connect the Stereo Audio outputs (Red-Red, White-White) of the DVD Player to the matching Inputs of your TV.
- Connect the Power Cord to the DVD Player and AC Power Outlet.
- Turn on the TV and DVD Player (power switch on back) and select the Video Input on your TV. On some models, this may be called "Input 1" or "Aux In". You should now see the DVD Player's splash screen on your TV.



2 Connecting to a TV with S-Video In and Stereo Audio In

If your TV has an S-Video Input, it's recommended that you use this connection. S-Video separates brightness and color signals, resulting in higher video quality than Standard Composite Video. *You must purchase a separate S-Video Cable for this connection (not included).

- In order to activate the S-VIDEO Output, you must first connect the unit using the COMPOSITE Video Output as described in Section 1.
- Enter the SETUP Menu and change the VIDEO OUTPUT setting to S_VIDEO (See Page 31). *For Help on using the SETUP MENU, see Page 28.
- Now that the S-VIDEO Output is Active, connect the S-Video Out from the DVD Player to the S-Video In of your TV and disconnect the COMPOSITE Cable.
- If you are not using a separate receiver for audio, connect the Stereo Audio outputs (Red - Red, White - White) of the DVD Player to the corresponding Inputs of your TV
- Select the S-Video Input on your TV. On some models, this may be called "Input 2" or "Video 2". You should now see the DVD Player's splash screen on your TV.





Component Video Connections

3 Connecting to a TV with Component Video Inputs

In order to enjoy the highest Video Quality available from your DVD Player, you must use a TV equipped with Component Video Inputs. If your TV supports Component Video, it's recommended that you use this connection. Component Video separates the Video Signal into three separate "components" (Y-Cb-Cr), resulting in a higher quality picture than S-Video or Standard Composite Video. *You must purchase a set of three (3) Component Video Cables for this connection (not included).

- In order to activate the COMPONENT VIDEO Output, you must first connect the unit using the COMPOSITE Video Output as described in Section 1.
- Enter the SETUP Menu and change the VIDEO OUTPUT setting to YCbCr (See Page 31). *For Help on using the SETUP MENU, see Page 28.
- Now that the COMPONENT Outputs are Active, connect the COMPONENT VIDEO Outputs from the DVD Player to the inputs on your TV and disconnect the COMPOSITE Cable.
- Select the Video Input Channel on your TV that corresponds to the COMPONENT Video Inputs. On some models, this may be called "Input 3" or "Video 3". You should now see the DVD Player's splash screen on your TV.




Digital Audio Connection

4 Using the CoAxial Digital Audio Output Connection

Your DVD Player features a Digital Audio Output to provide the ultimate in realism for your Home Theater experience. Use this option to get the most out of discs recorded with Dolby 5.1 Digital Surround Sound or Digital Theater System (DTS) by sending the encoded, or "RAW" digital audio signal to your Receiver for decoding. You must be using a Digital Receiver with 5.1 Channel Decoding and a CoAxial Digital Input to take advantage of this feature.


- You must purchase a separate Coaxial Digital Audio Cable for these connections, as these cables are not included with the DVD Player.
- Connect the Coaxial Digital Audio Out of the DVD Player to the corresponding Input of your Receiver.
- Adjust your Receiver's Input Source Setting to the correspond with the Digital Audio In.



Getting Started - Powering On & Playing a Disc


After Video and Audio Cables are Connected and Power is Applied

Once the DVD Player is properly connected to your TV and possibly your receiver also, turn on your TV and make sure it's set to the correct input channel. The video input is usually configured as channel 0 or 1 on most TVs, but may be referred to as "Input 1" or "Aux In" or similar names. These procedures assume you are using a NTSC-compatible TV - standard for North and South America. If you are using a PAL-type, you will need to change the TV Type first. In this case, see **Adjusting Audio and Video Settings**.




Power on the DVD Player

Push the Power button firmly to turn on the player. You should see the message "ON" in the DVD Display. Then, the player will attempt to read a disc. With no disc in the unit, the message INSERT DISC will be displayed.



Powering on from the Remote

Once the power button is pushed in, the unit can be turned off and on by the remote. When the unit is turned off by the remote, it will go into STANDBY MODE. This allows the unit to be quickly "awakened" by pressing the POWER key on the remote again. When the unit is in standby mode, the standby LED, located to the left of the disc tray, will glow.




Opening the Disc Tray

Press the OPEN/CLOSE button on the remote or on the player (to the right of the disc tray) to insert a disc. There are two grooves in the disc tray - 12cm and 8cm. Make sure the disc is properly set into the tray. Small 8cm discs must be positioned exactly in the middle groove. Press the OPEN/CLOSE button again to close the disc tray. You will see the message READ on the display. Once the disc is read, you should see the menu screen for DVD discs, or hear sound for an Audio CD. If a menu is present on the disc, you will see the word ROOT displayed. This lets you know you are at the beginning menu of the disc.



The Play Button

Most DVDs will automatically display a "root" (first layer) menu when inserted. However, some discs will require you to press the PLAY button. Also, the PLAY button can usually be used to quickly start a DVD movie when pressed with the root menu displayed. This function varies with discs.




Quick Tips

About Standby Mode


- Your DVD Player is equipped with a power-saving feature called **STANDBY MODE**. When you press **POWER** on the Remote to turn off the unit, it will enter standby mode, indicated by a glowing LED to the left of the disc tray, where it can be quickly awakened by pressing **POWER** again.
- When the unit has not been used for a length of time - about 25 minutes - the unit will automatically enter standby mode to save power.

Stopping and Pausing Play




To Stop Disc Play

Press the STOP button to stop playback of the disc. With Audio CDs, VCDs and DVDs, after the STOP button is pressed, the message HOLD will be displayed. The stop point is now saved and you can resume playback by pressing PLAY. Press the STOP key again to reset the play position to the beginning of the disc. You must press the STOP button twice to access some functions in the DVD Player Setup Menu.



Pausing Disc Play


With DVDs and VCDs, you can pause playback on a still frame with the PAUSE button. Pressing the PAUSE button again resumes normal playback. Sound is muted when the video is paused. Pressing PAUSE while playing Audio CDs will mute the sound and hold the play position. Press PAUSE again to resume playback.



Quick Tips

Screen Saver



- When a DVD or Video CD remains paused on a still frame for an extended length of time - approximately 3 minutes - the Screen Saver will be activated.
- The Screen Saver guards against damage to your TV screen, or "screen burn" which could result in residual images on the TV's CRT tube.
- You can disable the Screen Saver in the DVD Player Setup. See **Adjusting Video and Audio Settings**.




Navigating Disc Menus

Using MENU and TITLE Buttons to Access Menus on DVD and VCD Discs

Most DVDs and some VCD discs feature menus that will allow you to navigate the various Chapters, Special Features and Setup Options available for the disc. Some menus will automatically be displayed when you insert a disc. To access menus at any time, use the MENU and TITLE buttons. If you see the symbol below when attempting to select a Title or Menu, it means that this type of menu is not available on the disc. Title menus, for example are not available on some DVDs.



OR




Entering the DVD or VCD Menu

Press the MENU / PBC button to access the DVD menu. If the disc does not have a menu, the symbol described above will be displayed. Used with Video CDs, pressing this button will Enable / Disable the PBC (Play Back Control) menu system. With PBC enabled, the disc menu will be shown. The disc will simply play all tracks in sequence with PBC disabled.

Entering the Title Menu

Title menus are available on some DVDs. These menus allow you to select a particular Title or Chapter to play. With some DVD discs, pressing this button will bring up the normal DVD menu. If the "not available" symbol is displayed on screen, this feature is not available on your disc.




Navigate with the ARROW Buttons

Use the ARROW buttons to navigate through the menu - left, right, up, down.




Confirm Menu Choices with ENTER

Press ENTER on the desired menu option to execute that function.



Exit Menu and Resume Play

While using a disc menu, use the RETURN key to resume playback from the point on the disc that the menu was activated. While playing a disc, press RETURN to return to the last menu accessed.



Fast Forward/Reverse & Slow Motion Scanning


Finding a Position on the Disc Using the Search Function

Your DVD Player features a Search function that will allow you to scan through video at fast or slow speeds to find a specific position. The scan functions available will depend on the type of disc you are using. With DVD discs, you may utilize all the available scanning functions, including Fast Forward and Fast Reverse, both at x2, x4, x8 and x16 speeds, as well as Slow Motion Forward and Reverse at 1/2, 1/4, 1/8 and 1/16 speeds. VCD and CD Audio discs have limited scan functions. VCDs do not support Slow Motion in Reverse. Audio CDs do not support Slow Motion scanning.




Fast Forward or Reverse Scanning

The Fast Forward (FF) and Fast Reverse (FR) buttons are only functional while the disc is playing. To start searching, press the button for the desired direction. The beginning scan speed is 2x, or twice the normal speed. Press the button repeatedly to cycle through all available scanning speeds. Press the PLAY button to resume normal viewing.



Slow Motion Scanning


With DVDs and Video CDs, you can slow the speed of playback to a mere fraction of the normal speed. VCDs support only forward Slow Motion scanning. While the video is playing, press the SLOW button. The playback speed will slow to 1/2 normal speed. To cycle through all speeds, and to switch to Reverse Slow Motion, continue to press the SLOW key. Press PLAY to resume normal playback.



Skip Forward and Skip Back


Advancing to the Next Track or Skipping Back Through Tracks

Your DVD Player provides a convenient method for advancing or skipping back through tracks, chapters, songs or other segments on DVD, VCD or Audio CD discs.



The Next and Previous Track Buttons

Use the NEXT >>> and PREVIOUS <<< buttons to skip through the tracks on DVDs, VCDs and Audio CDs. Pressing the PREVIOUS button will return play position to the beginning of the current track. Pressing PREVIOUS again will return to the beginning of the previous track and so on. Advance through the remaining tracks on the disc by using the NEXT button. When the last track is reached, however, pressing the NEXT will not return to the first track on the disc. This principal also holds in the reverse direction.



Jumping to a Specific Chapter/Track or Time Position

You may Choose a Specific Track or Time Position to Playback


There are many options available to choose the beginning playback point on DVDs, VCDs and Audio CDs. You may use the GOTO button, or enter a Track Number directly using the NUMBER buttons.



Select the GOTO Button

With DVDs, when play is stopped, press the GOTO button to select a Title on the disc. When a DVD is playing, press GOTO once to select the Chapter you wish to jump to. Pressing GOTO again will allow you to enter the time (Hours, Minutes and Seconds) of the position on the disc you wish to begin playback.


For VCDs and Audio CDs, pressing GOTO once while play is stopped will allow you to enter a time (out of total disc time) to begin playback. Press GOTO again to select a specific track number. While a VCD or Audio CD is playing, press GOTO multiple times to cycle through the options of entering a Track Time, Total Disc Time, or Track Number to begin playback.



Enter Values with Number, C and +10 Buttons

Use the Number buttons, along with the C (Clear) and +10 keys, to enter numerical values representing Track or Chapter Number or Time Position. If you wish to clear an entry, press the C button repeatedly to backspace through the digits you want to delete.

To enter a number greater than 10, press the +10 button once for each 10s value of the number. For example, if you wish to enter "32", press the +10 button three times, then press "2". The +10 key will not function when there are fewer than 10 tracks to choose from.



Quick Tips


Skipping the GOTO Button

- If you do not wish to use the time functions available with the GOTO key, you can simply press a number button corresponding to the Title, Chapter or Track you wish to go to. The available options are determined by the type of disc and whether or not the disc is in playback mode.
- With DVD discs, pressing a number button in Stop mode will allow you to choose the Title and Chapter you wish to navigate to. In Play mode, you will have the option of entering the Track Number of the current title you want to play.
- With VCD and Audio CDs, enter the number of the track you want to play in stop mode or play mode to directly jump to that position.
- VCDs may require the PBC function to be disabled before directly selecting tracks with the number buttons.

Previewing Titles, Chapters or Tracks Before Playback

See or hear a Preview of the Titles, Chapters or Songs on a Disc using INTRO

Your DVD Player features a great way to introduce yourself to the various content of DVD, VCD and Audio CD discs. Using the INTRO button, you can see a preview of all the titles available on DVD discs, such as Special Features, Movie Formats and Coming Attractions. You can also listen to a short preview for each song on an Audio CD or see a short video preview for each track on VCDs.




Select the INTRO Button

If you have an Audio CD inserted, you will see the message SCAN on the screen. Wait for the player to scan the disc. Shortly, a short preview of each song will be played in the normal track order. You can listen to as many intros as you wish, as the previews will repeat from the beginning of the disc. When you decide to play a track, press the ENTER key (Step 3).

With DVDs and VCDs, you'll be given a choice of preview options on screen. These options will depend on the type of disc and whether or not playback mode is active. In Stop Mode using a DVD disc, you can choose to preview Titles. In DVD Play Mode, the additional options of Chapter Digest, Title Interval and Chapter Interval are available. VCD discs have similar options, with Track Digest and Disc Interval available in Stop Mode, and the additional option of Track Interval in Play Mode. Intervals are divisions by time period rather than chapter or track.

If you wish to Exit the INTRO Menu, simply press INTRO again.




Navigate with the ARROW buttons

Use the ARROW buttons to navigate through the menu - left, right, up, down. To choose a Digest type, press ENTER. You will see short preview of each Title, Chapter or Interval, depending on which option you chose. Use the Arrow buttons to choose one of the windows to begin play at this position on the disc. Or, navigate back to the previous menu.



Confirm Menu Choices with ENTER


Remember that you press ENTER on the desired video window or option to begin play or execute a function. To Exit the INTRO menu at any time, press INTRO again.



Saving Locations for Quick Play with Bookmarks


Mark a Point on the Disc to Come Back to Later with the BOOKMARK Button

While you're watching a DVD or listening to an Audio CD, you can easily "mark" a point on the disc that you would like quick access to later on. For instance, if you see a particularly interesting scene and would like to watch it again when the DVD is over, add a Bookmark. You can add up to 12 bookmarks and browse through them after watching the movie! You can also use bookmarks with VCDs and Audio CDs.





Pause Disc Playback

You'll probably want to Pause playback at the point where you wish to add a Bookmark before accessing the Bookmark Menu, although this is not required. You may also want to use the Fast Reverse Scanning feature to backup to the point that you would like to Bookmark. For more on this function see **Fast Forward / Reverse and Slow Motion Scanning**.



Press the Bookmark Button

Press the Bookmark button to bring up the Bookmark Menu Screen:




Select the Location to Store the Bookmark

Use the ARROW buttons to navigate through the available Bookmark locations (1-12) to the one that you would like to save the current disc play position to. In the example here, all locations are open, so we'll choose the first one.




Press ENTER to Save the Bookmark Location

Now the play position is saved as a Bookmark. Notice that the Track and Time information are stored for the Bookmark in position one:



Press BOOKMARK to Exit the Bookmark Menu

Now, you can resume playback and return to the Bookmarks you've saved at any time using the BOOKMARK button, selecting the Bookmark to play and pressing ENTER or PLAY.




Quick Tips

- To clear Bookmarks from the menu, navigate to the position you want to delete and press C.
- Bookmarks are only active while a particular disc is loaded. Once power is turned off or the disc is ejected, the stored Bookmarks will be lost.
- You can store up to 12 Bookmarks.

Repeating a Title, Chapter/Track or Disc

Repeat a Single Track on an Audio CD or an Entire DVD Disc

Your player has many options for repeating segments of DVDs, VCDs, and Audio CDs. This section covers how to repeat segments already defined on the disc, such as a Chapter or Track. The next section deals with creating your own segments to repeat.




Using the REPEAT - 1/ALL Button

While you're viewing a video disc or listening to an Audio CD, press the REPEAT - 1/ALL button repeatedly to cycle through the available repeat options. The status of the repeat option will be displayed in the upper left-hand corner of the screen.


With DVDs, press the REPEAT - 1/ALL button once to repeat the Current Chapter, twice to repeat the Current Title, and three times to repeat the Entire DVD. VCDs will allow repeat playback options of the Current Chapter or All Chapters, but only if PBC is disabled. To disable PBC, press the MENU/PBC Button. With Audio CDs, you'll have the option to repeat the current Track or the complete CD.

To Cancel Repeat Play, simply press the REPEAT - A/ALL button until the Screen no longer displays a repeat option icon.



Repeating a Specific Time Segment

If you would like to repeat only a segment of an Audio Track, VCD Movie or DVD Title, simply mark the beginning and endpoints of the segment with the REPEAT A-B button.



Using the REPEAT A-B Button

While viewing or listening to a disc, when you get to the point that you would like to mark as the Beginning of your repeating segment, press the REPEAT A-B button. You will see this symbol:  letting you know that the start point of your repeat segment has been marked. Next, you will enter the endpoint of the segment you want to repeat.

When you reach the ending for your segment, press REPEAT A-B a second time. Now, the symbol  will be displayed, letting you know that the player is in A-B Repeat mode, and will continuously play the segment you defined until you cancel repeat mode.

To Cancel A-B Repeat Play, simply press the REPEAT A-B button again. The repeat status icon disappears from the screen, and play continues as normal.


Quick Tips

- When using A-B Repeat with an Audio CD, your segment must be no longer than a single track.
- When using A-B Repeat with DVDs, your segment must be no longer than a single Title.

Playing Tracks in a Particular Order with Program Play



Create Custom Playback Programs of up to 20 Steps

If you would like to program the Chapters or Tracks on your disc to play in an order you specify, create a custom playback program with the PROGRAM button.




Select the PROGRAM Button

You will see the Program Menu on the screen. There are 10 locations for adding Track Numbers on each page, with a total of 2 pages. Shown here is the menu you will see when a VCD or Audio CD is inserted. The Program Menu for DVD discs will have an additional option for Title Number.



Navigate with the ARROW Buttons

Use the ARROW buttons to navigate through the available program locations (1-10), go to the NEXT page, or EXIT the Program Menu.



Using the Number, C and +10 Buttons



Use the Number buttons, along with the C (Clear) and +10 keys, to enter the Track or Chapter you want to play in each position. If you wish to clear an entry, press the C button repeatedly to backspace through the digits you want to delete.

To enter a number greater than 10, press the +10 button once for each 10s value of the number. For instance, if you wish to enter "32", press the +10 button three times, then press "2". The +10 key will not function when there are fewer than 10 tracks to choose from.



Navigate to START and Press ENTER

After you've entered your track numbers in the locations you want to play them, use the ARROW buttons to navigate to START on the bottom of the screen. Press ENTER to start the program. In this example, track 5 will play first, track 12 second, and so on.



Quick Tips

- To Exit Program Play, press STOP, then PLAY.
- Programs will be erased when power is turned off or the current disc ejected.
- To Erase the current program, press PROG and navigate to STOP. Press ENTER.

Playing MP3 Files with the MP3 Navigator

Your DVD Player is also a Feature-Packed MP3 Player!

When you insert an MP3 disc, the player will launch the MP3 Navigator, an on-screen program that lets you easily select and play MP3 files stored on CD-R or CD-RW discs. The MP3 Navigator gives you several options for MP3 Playback, including Program and Repeat modes.

Folder List
Lists the current folder and total folders on the disc.

Program Mode
Determines how files will be organized and played.


FOLDER : 000/003	FILE : 001/025
Rock and Roll	MP3 Home Again
Slow Blues	MP3 Black in Back
Pop and R&B	MP3 Smokin Joe
	MP3 In the Cage
NORMAL MODE	NORMAL

File List
Lists the current file and total files on the disc.

Repeat Mode
Sets Repeat Play options for files, folders or discs.

Navigation Buttons


A list of buttons that are functional in the MP3 Navigator screen.



Choose a Program Mode with the PROG Button

There are three Program Modes available with the MP3 Navigator. With play stopped, press the PROG button to switch between the Modes:


- **Normal Mode** - Displays files in normal "Directory \ Files" fashion. Navigate directories with ARROW keys and play files with the ENTER button. To navigate or select another file from the menu, you must press STOP first.
- **File List** - Lists only files. All Files on the disc are displayed in one long list without any directory information.
- **Program List** - This is a special mode that allows you to define a List of which songs to play. Program List Mode displays all the files on the disc in one long list to the left. Simply move through the list and press ENTER on the songs you wish to add to the Program List on the Right.



Select the Repeat Mode with REPEAT - 1/ALL

The Repeat Modes give you the options to repeat a single file, entire directory or a whole disc, as well as the option to play a single file and stop. You select from the following choices by pressing the REPEAT - 1/ALL Button:

- **Normal** - Simply plays the files normally with no Repeat functions active.
- **Single** - Play only one file. Plays the current track and Stops.
- **Repeat One** - Repeats the current track continuously.
- **Repeat All** - Repeats all tracks on the disc. This option is available in FILE LIST and PROGRAM LIST Program Modes.
- **Repeat Folder** - Repeats all tracks in the current directory. This option is available in NORMAL Program Mode.




Navigate to a File

Use the arrow keys to select the file you wish to play.



Press ENTER to Play

Pressing ENTER will play the file you selected or start your program.



Quick Tips

- MP3 Files must be saved with the extension ".MP3" (upper or lower case) in order to play correctly.
- You can have a maximum of 250 Files or Folders.
- MP3 Discs must have a "Closed Session" in order to play properly.


Viewing JPG Picture Files on Your TV

You Can Play Slide-Shows of JPG Images Stored on CD-R/RW Discs

When you insert a disc containing JPG files, the player will launch the JPG Navigator, an on-screen program that lets you easily select and play JPG files one at a time or in Slide-Show mode. JPG Picture files must be saved with the .JPG extension. Example: "Vacation1.jpg"

Folder List
Lists the current folder and total folders on the disc.

Program Mode
Determines how files will be organized and played - see pg 24 for details.



File List

Lists the current file and total files on the disc.

Repeat Mode

Sets Repeat Play options for files, folders or discs - see pg 24 for details.

Navigation Buttons

A list of buttons that are functional in the JPG Navigator screen.



1



Press ENTER to Begin a Slide-Show

Use the ARROW keys to select the folder or file you want to display. Then, press ENTER to begin Slide-Show mode. With the Repeat Mode set to NORMAL (default), all files will be displayed in the order they appear on the disc for about 3 seconds each. When all files have been displayed, the Slide-Show will end. By using the REPEAT 1/ALL button, however, you can setup continuous play by repeating a folder or the entire disc - see pg 24 for details on Repeat Mode.

You can also use the PROG button to select a different Program Mode, which determines how the files are organized and displayed. This functionality is the same as with MP3 files and is covered on pg 24.

2



Select a Transition (Wipe) with PROG

While the Slide-Show is in progress, you can choose from a wide variety of transitions, or "wipes" that will animate the change from one picture to another. Use the PROG key to cycle through the transition modes listed to the right.

3



Press MENU to Exit the Slide-Show

You can press the MENU/PBC button at any time while to exit the Slide-Show and return to the JPG navigator. Alternatively, to view a thumbnail summary of all files in the current directory, press STOP.

More JPG Functions

Displaying Thumbnail Images


During Slide-Show mode, you can press the STOP button to view thumbnail images of all files in the current directory. Navigate with the ARROW keys and press ENTER to display a file. Move between pages with SKIP NEXT/PREVIOUS buttons.

Rotating and Flipping Images

While a picture is displayed, you can Rotate the image by pressing the LEFT/RIGHT ARROW keys. To Flip the image vertically, press the UP key. To Flip Horizontally, press DOWN. To resume the Slide-Show, press PLAY.

Zooming In/Out on an Image

While a picture is displayed, press ZOOM, then ►► to Zoom-In (150-200%) or ◄◄ to Zoom-Out (75-50%). To Pan the image Up/Down/Left/Right, use the ARROW keys.



Quick Tips


Transition Modes

1. Wipe from Top
2. Wipe from Bottom
3. Wipe from Left
4. Wipe from Right
5. Diagonal (Left Top)
6. Diagonal (Right Top)
7. Diagonal (Left Bottom)
8. Diagonal (Right Bottom)
9. Horizontal from Center
10. Vertical from Center
11. Horizontal to Center
12. Vertical to Center
13. Horizontal Blinds
14. Vertical Blinds
15. Box Edge to Center
16. Random

Using the Zoom Function


You can Zoom In or Out during Playback or on a Still Frame

Want to take a closer look at something you see in a DVD or VCD movie? Use the Zoom function. The Zoom function lets you enlarge the Video Image 2, 3 or 4 times the original size. You can also Zoom Out to ½, 1/3 or 1/4 size. Zoom works on a still frame, as well as during Video Play.





Pause Disc Playback (Optional)

Zoom is most effective if you Pause the video on a single frame to examine. However, Zoom will work while playing a movie as well. If you wish to Pause the action, press the PAUSE button.





Select the ZOOM Button

Press the ZOOM button repeatedly to select the Zoom Level you want. The Zoom Level is shown on the screen next to the Zoom Icon as shown:




Navigate with the ARROW Buttons

Use the ARROW buttons to move to the parts of the screen you would like to see closer. Pressing the LEFT ARROW button will move the focus of the Zoom to the left, and so on.



Return to Normal Viewing

Press the ZOOM button repeatedly until the Zoom Icon is no longer on the screen to return to normal playback mode.



Quick Tips


- Picture quality of the Zoomed Image will depend on the quality of Video and Television
- Zoom will work only on DVDs and VCDs, not the Setup menu.

More Audio & Video Functions



Suspending Audio with the MUTE Button


To temporarily cancel the Audio of the disc you're listening to or watching, simply press the MUTE button. You'll see an indicator on screen letting you know that the player is in MUTE mode. Press MUTE again to resume normal playback with Audio.



EFFECT - Reverb and Equalization Effects


Use the EFFECT button to access a wide variety of Equalization or Reverberation effects, depending on what type of disc is inserted. Reverb effects are meant to duplicate the natural "reverberation" of sound that is produced in a large structure, such as a cave or arena, giving you the effect that you're listening to your music in different venues. Equalization settings change the Bass, Treble and Midrange frequency mix of the sound.

When used with Audio CDs, VCDs or DVDs without surround sound, the EFFECTS key cycles between several Reverb effects, including CONCERT, LIVING ROOM, HALL, BATHROOM, CAVE, ARENA and CHURCH. Used with DVDs recorded with Surround Sound, the EFFECT button activates several Equalization effects, including Rock, Pop, Live, Dance, Techno, Classic and Soft. To turn effects OFF, simply press the EFFECTS button until the word OFF appears on screen.




Changing Audio Settings - AUDIO Button

You can switch between the various Audio modes available on DVD discs with the AUDIO button. Used with DVDs, AUDIO cycles between the modes offered on the disc, including DTS, Dolby Digital 5.1 and Stereo Audio. Video and Audio CDs offer fewer audio options, including Mono Left/Right, Mix Mono and Stereo.




Multi-Angle Support - ANGLE BUTTON

Some DVDs are recorded with a feature called "Multi-Angle View". If you are viewing a DVD that includes this feature, press the ANGLE button to switch between available Angles for a given scene. Press ANGLE until normal view returns to exit.




SUBTITLE - Explore Subtitle Languages

Use the SUBTITLE button with DVDs recorded with Subtitle tracks. This key will allow you to switch between the available languages on the disc. To turn off Subtitles, press SUBTITLE until OFF appears on screen.



Get Playback Session Info with DISPLAY

Wonder how much time is left in the movie you're watching or the CD you're listening to? Press the DISPLAY button to find this type of information about the current disc. Continue to press DISPLAY to cycle through various info, such as Elapsed and Remaining Time for the Current Track/Chapter and Elapsed and Remaining Time for the Title or Disc. To clear the on-screen Display, press until DISPLAY OFF appears on screen.



Quick Tips

- Most functions depend on the type of disc.
- Functions vary widely among DVD discs. The unavailable symbol will be displayed when you try to use a function that's not available on your disc.



Using the On-Screen Setup Menu


Adjusting Video and Audio Settings in the DVD Player Setup

Your DVD Player features an on-screen Setup Menu that allows you to adjust settings for your Video and Audio preferences, and enable player features like Parental Lock. When you change settings in the Setup Menu, they are stored even when power is turned off. If you wish to return to the factory defaults, they can be easily reset in GENERAL SETUP.





Stop Disc Play (Optional)

For some Setup Options to be available, you must completely stop disc play. Press the STOP button twice to stop play of the disc. With Audio CDs, VCDs and DVDs, after the STOP button is pressed once, the message HOLD will be displayed on front of the Player. At this point, press STOP again so that the display reads "STOP".





Press the SETUP Button

Press SETUP to enter the on-screen Setup Menu. The initial screen contains the following categories:




Move Around the Menu with the ARROW Keys

Use the ARROW buttons to move around the menu. In this example, we'll hit the DOWN key to go to AUDIO SETUP, then hit ENTER to enter that Menu. Then we'll hit the DOWN key again to select DOWNMIX. Pressing the RIGHT key allows us to choose "STEREO", and a hit of the ENTER key confirms our choice.



Press SETUP to Exit the On-Screen Setup Menu


You can exit the Setup menu at any time by simply pressing the SETUP key.



Parental Lock and General Options

Exploring the General Setup Page

The General Setup Page contains many important options for your DVD player. Along with options for basic viewing features such as CLOSE-CAPTIONS, this menu is where you can set a password to control the Parental Lock function, which lets you limit the play of discs beyond a rating you specify. The General Setup page also contains the DEFAULT option, which you can use to reset all player options, except the Parental Control, to default factory values. Now let's take an in-depth view of the General Setup Page.



ANGLE MARK - ON/OFF

When used with discs supporting multi-angle features, the Angle Mark continuously displays the current angle you're viewing on screen. Setting ANGLE MARK to OFF will cancel continuous display, and the current angle will be displayed on-screen for just a few seconds after an angle change.

CLOSE-CAPTIONS - ON/OFF

Not all discs support Close Captions. However, setting CLOSE-CAPTIONS to ON will display captions when supporting discs are used. If you don't wish to automatically enable captions, set this option to OFF.

SCREEN SAVER - ON/OFF

The Screen Saver protects your TV's cathode-ray tube from "screen burn" that could result from a static image being displayed for a prolonged period. The Screen Saver will automatically start within a few minutes of video inactivity. To disable this function, set this option to OFF.

PARENTAL - G, PG, PG-13, PG-R, R, NC-17, ADULT / OFF

The Parental Lock allows you to limit the use of your DVD Player to only those DVD discs that do not exceed the rating you specify. When the parental control is set, DVD discs that support Parental Control will play only after the correct password has been entered. Non-supporting discs, however, will be "immune" to lockout. When you attempt to change the parental control setting, you are prompted for a password. This of course makes sense, as this option would be useless if your kids could simply enter the Setup Menu and disable it! The factory default password, which cannot be removed or changed, is 1369. You may use this password for Parental Lock functions, or input one additional password. This is covered in the next section. *You must completely stop the player by press STOP twice to change this setting.

PASSWORD - CHANGE

Here is where you can set an additional password to the default factory password. The procedures to change an existing password or enter a new password are the same - you must enter the OLD PASSWORD, then key in your new password twice to confirm. If you are entering a new password, or replacing a password you have forgotten, use the factory default password of 1369 as the OLD PASSWORD. If you are changing a previously entered password, you may enter that value as the old password.

DEFAULT - RESET

If you would like to return all settings of your DVD Player's Setup to the factory defaults, choose DEFAULT - RESET. This will reset all values for General, Audio, Video and Language settings, with the exception of the Parental Control and Password. After all, the Parental Control and Password features would be of little use if your kids could simply clear them with a reset. *You must completely stop the player by press STOP twice to change this setting.

Quick Tips

- Remember to keep in mind that the key to the Parental Control feature is the factory default password of 1369.
- Consequently, your player may not be secure if this manual is accessible by your children.




Audio Setup Options

Adjusting Audio Settings in the Audio Setup Page

The settings you choose in the Audio Setup Page will be determined by the type of audio equipment you are using with the DVD Player. The factory default settings are configured with the assumption that you are using the player with a standard Television supporting Stereo Audio Inputs. This menu will allow you to enable the Digital Audio Output if you wish to use the Coaxial Digital Audio Output with a Digital Receiver.

AUDIO OUT - SPDIF OFF/RAW/PCM

SPDIF (Sony/Philips Digital InterFace) refers to the digital audio format used by most consumer electronics equipment, as well as the Coaxial Digital Audio Output connector. If you are using the Stereo Audio Outputs, leave SPDIF set to OFF. If you wish to use the Coaxial Digital Output, change this setting to RAW or PCM. Generally, the RAW setting is used with receivers capable of Dolby Digital 5.1 or DTS 5.1 channel decoding, while the PCM setting is reserved for two channel equipment.



DOWNMIX - (LT/RT)/STEREO

Since most DVD discs feature Dolby 5.1 channel soundtracks, you'll need to use the Downmix feature when watching these movies with only a Stereo TV or Receiver. There are two Downmix options: LT/RT and STEREO. The STEREO setting should be used for most Televisions and Stereo equipment. Generally, the LT/RT option should be used only with Dolby Pro Logic receivers capable of decoding this type of signal.

DUAL-MONO - STEREO/L-MONO/R-MONO/MIX-MONO

These settings are generally for CDs or VCD that offer only Mono audio tracks. In this case, the STEREO option will function as normal stereo, while the L-MONO and R-MONO will send the mono output to only one speaker. MIX-MONO will send the same mono output to both speakers.

DYNAMIC - OFF/FULL

Sometimes called "midnight mode", Dynamic Range Compression aims to make watching a movie at low volumes more enjoyable by boosting the quieter sounds while suppressing the louder sounds. This reduction in the difference between the low and high audio levels is known as "compression". You can adjust the level of this compression from OFF to FULL, using the UP/DOWN ARROW buttons.

Quick Tips

- Remember that you must completely stop the player to change some setup options.
- Press the STOP button twice to completely end playback.




Video Setup Options

Adjusting Video Settings in the Video Setup Page

The Video Setup Page contains settings that will be determined by the type of TV you're using, along with settings based on your personal preferences. You can adjust the player to function with NTSC or PAL television types, as well as normal and wide screen models. Also, display properties such as Sharpness, Brightness and Contrast may be adjusted with this menu.

TV TYPE - PAL/MULTI/NTSC

Your DVD Player will work with TVs based on the NTSC and PAL standards, as well as TV designed to function with both standards, or "Multi" models. NTSC is the standard TV system used in the USA, Canada, Japan and many other countries. The PAL TV system is used in Europe, Africa and the Middle East, among other places. Refer to your TV's documentation to make sure which model you have.



Quick Tips

Use Caution when Changing the TV Type

Choosing the wrong TV Type may cause the screen to flicker and become unreadable. So, change this setting with caution. If you have changed the TV Type to the wrong setting, you may need to program the correct setting without being able to read the display. In this case, take the disc out of the player and turn the power off. After a few seconds, turn the power on and input one of the following code sequences to change the TV Type:



To Reset to NTSC:

STOP > SETUP > DOWN ARROW > DOWN ARROW > ENTER > RIGHT ARROW > DOWN ARROW > DOWN ARROW > ENTER

To Reset to PAL:

STOP > SETUP > DOWN ARROW > DOWN ARROW > ENTER > RIGHT ARROW > UP ARROW > UP ARROW > ENTER

TV DISPLAY - (NORMAL /PS4:3)/(NORMAL/LB4:3)/WIDESCREEN16:9

You can setup your DVD Player to work with normal and wide screen televisions. If you are using a wide screen TV, set this option to WIDESCREEN16:9 to match the aspect ratio of your TV. When used with a normal TV (4:3 aspect ratio), the NORMAL/PS4:3 setting results in the typical "Pan & Scan" display, where a movie is clipped on the sides to fit into the TV screen. The NORMAL/LB4:3 setting will enable the "Letterbox" format, where the movie is presented in wide screen format with black lines at the top and bottom of the screen.


SHARPNESS, BRIGHTNESS & CONTRAST - HIGH/MEDIUM/LOW, +-16

You may adjust the Sharpness of the picture to one of three levels: High, Medium or Low. The Brightness and Contrast are adjustable from -16 to +16. Use the UP and DOWN ARROW keys to adjust the Brightness and Contrast.

VIDEO OUTPUT - YCbCr/S-VIDEO

Choose the setting that corresponds to the Video Output Connector you are using:

- 1 COMPOSITE VIDEO OUT:** This is the typical connection type supported on most TVs. This connection does not require a change to the VIDEO OUTPUT setting.
- 2 S-VIDEO OUT:** You must first connect the unit using the COMPOSITE VIDEO connector and cable in order to enter SETUP and change this setting to S_VIDEO, activating the S-VIDEO Output. Next, connect the unit using the S-VIDEO cable and unplug the COMPOSITE video cable. Switch the TV's Video Input setting to S-VIDEO.
- 3 COMPONENT VIDEO OUT:** You must first connect the unit using the COMPOSITE VIDEO connector and cable in order to enter SETUP and change this setting to YCbCr, activating the COMPONENT VIDEO Outputs. Next, connect the unit using the COMPONENT VIDEO cables and unplug the COMPOSITE video cable. Adjust the TV's Video Input setting to correspond to the COMPONENT Input.



Language Setup Options

Setting Language Options for Setup and DVDs


The Language Setup Page allows you to change the language the player will use for the On-Screen Display (OSD), as well as the default language for movies with multiple language tracks. Keep in mind that if the DVD you're using does not support the language you choose, the default of the disc will be used. This also applies to Subtitle and Disc Menu settings.

OSD LANG - ENGLISH/FRENCH/GERMAN/ETC.

With this setting you can change the language of the On-Screen Display menus. This will make it easier to change other options with the Setup Menu.

AUDIO, SUBTITLE, DISC MENUS - ENGLISH/FRENCH/ETC.

You can set the player to use a preferred language for DVD Audio Tracks, Subtitles and Menus. Of course, these settings will only take effect for DVD discs that support the language you have chosen. If the DVD discs do not support your preferred language, the default for the disc will be used instead.



Quick Tips

- Remember that you must completely stop the player to change some setup options.
- Press the STOP button twice to completely end playback.



Troubleshooting Common Problems

.....

The DVD Player Does Not Power On

- The AC Power cord may be loose or not plugged in. Make sure the power cord is secure in the AC socket and the connector on the back of the player.
- The unit may be in Standby Mode. In this case, the Standby LED to the left of the disc tray will be glowing. Turn the player on with the remote POWER button, or turn the unit off, wait for a few seconds, then turn the unit on with the front Power Switch.
- There must be a pause between powering the unit down and back on of a few seconds.

A Specific Disc Does Not Play

- The disc may be dirty. Try cleaning the disc.
- Make sure the disc is not in upside-down
- The region code of the disc may not match that of the player. In this case, the disc cannot be used.

The Remote Control Does Not Function

- Make sure you're aiming the remote directly at the player's remote sensor, located in the front display.
- Make sure there are no obstacles between the remote and the player.
- The batteries may be drained. Try changing the batteries in the remote.
- You could be using the remote too far away. Try within 4 meters of the player.

There is No Picture on the TV Screen

- Make sure the connections from the player to the TV are secure.
- Verify that the TV's channel is set to match the video input you're using. Refer to the TV's documentation.
- On most TVs the "Aux In", "Video In" or "A/V In" channel should match the video input connector.
- If you're using the S-Video connector, the TV may have a separate input channel for this type.

The Disc Doesn't Eject

- If the player is in Standby Mode with the glowing LED to the left of the disc tray, the disc will not eject. Turn the player on with the Remote Control and then eject the disc.

No Sound from TV or Speakers

- If the DTS soundtrack is enabled in the DVD Disc Menu, but you are using Stereo Analog audio, the sound will not work. Try switching the soundtrack to Dolby 5.1 or PCM mode in the Disc Menu.
- If you are using a Digital Receiver, you must enable SPDIF in the player's Setup Menu.
- Make sure the audio cables connecting the DVD player to your TV or receiver are secure.
- The movie is paused. There is no sound during Pause or Search modes.

Sound From Only Left/Right Front Speakers of 5.1 Channel System

- Use the MENU key to enter the disc's menu and check that the Audio Setup is set to Dolby/DTS 5.1 Audio.
- Make sure the SPDIF OUTPUT setting is on SPDIF/RAW in the Player Setup Menu. (See pg 30)
- The Disc may not support a Dolby/DTS 5.1 channel soundtrack.

Some Settings in the Setup Menu are Unavailable

- You must completely stop playback by pressing the STOP button twice.

Distorted Picture when Connected to a VCR

- This DVD Player is built with Macrovision copy-protection. This will distort the signal when used with VCRs. Connect the player directly to the TV.

The Player Turns Off on Its Own

- It is normal for your DVD player to power down into Standby Mode after about 25 minutes of inactivity to save power.

Specifications

Playable Discs

DVD, Audio CD, VCD, CD-R, CD-RW

TV Systems Supported

NTSC, PAL, MULTI

Laser

Semiconductor Laser, wavelength 650nm

Frequency Response (Digital Audio)

DVD Linear Sound: 48kHz sampling 4Hz to 22kHz
96kHz sampling 4Hz to 44kHz

Audio CD: 4Hz to 20kHz

Signal-to-Noise Ratio (Digital Audio)

More than 90dB

Audio dynamic range (Digital Audio)

More than 80dB

Harmonic Distortion (Digital Audio)

Less than 0.015%

Wow and Flutter

Less than $\pm 0.001\%$ (W.PEAK)

Connections

Component Video Out: (Y) 1.0Vpp (75 Ohm), Negative Sync, (Pb)/(Pr) .7 Vpp (75 Ohm)
S-Video Out: Mini DIN 4-Pin (75 Ohm)
Video Out: One Pin Jack, 1Vpp (75 Ohm)
Coaxial Digital Out: One Pin Jack, .5Vpp (75 Ohm)
Analog Audio Out: Two Pin Jacks, 2.0VRMS (470 Ohm)

Operating Conditions

5°C to 35°C (41°F to 95°F), Operation Status: Horizontal

Power Supply

AC 120V, 60Hz

Power Consumption

Normal Mode: 17W

Standby Mode: 4.8W

Dimensions

16-12/16" (W) x 3-3/32" (H) x 11-3/8" (D)
(427mm x 79mm x 290mm)

Weight

9.1 lbs. (4.14 kg.)

**Note: Design and specifications are subject to change without notice.*

Glossary of DVD-Related Terms

CD-R & CD-RW

Recordable Optical Disc formats that can be used as VCD or MP3 discs with your DVD Player.

Coaxial Digital Audio Connector

A digital audio connection used to connect a DVD player to a receiver or pre-amplifier. Transfers a "RAW" digital audio signal, minimizes signal degradation.

Component Video

Offers the best interface between a video signal source and a TV. Uses three RCA-type jacks to separate the component signals making up a video signal. A component video signal is comprised of the luminance (Y) signal and separate chrominance (PR and PB) signals.

Composite Video

The most common connection between a DVD Player and a video display, Composite Video uses a single RCA cable.

Dolby Digital 5.1

A digital surround sound system, capable of transferring up to 5 sound channels plus a sub-bass woofer, developed by Dolby Labs. Supported on most DVD discs.

DTS

Digital Theater System. Another digital surround sound system with 5.1 channels. DTS is supported on some newer DVD discs.

Dual-Layer DVD

A DVD disc that has two layers on each side. A single-sided, dual-layered DVD can hold almost four hours of video and audio, and is also known as a DVD-9.

DVD

Digital Video Disc. DVDs come in different formats, such as single-sided or double-sided. Each side can have a single layer or two layers of data.

DVD-5

A DVD that is single-sided, single-layer, holding up to 4.7 GBytes of data.

DVD-9

A DVD that is single-sided, dual-layer, holding up to 8.5 GBytes of data.

DVD-10

A DVD that is double-sided and single-layered, which holds up to 9.4 GBytes of data. This disc must be manually flipped to use both sides.

Home Theater

A system designed to re-create the movie theater experience in the home. A typical home theater system will have a DVD Player, TV, Receiver and Speaker System with 4 speakers and a subwoofer for surround sound.

MacroVision

Analog Copy Protection which scrambles video signal when used with VHS recorders. Also has an effect on some projectors and monitors.

Glossary of DVD-Related Terms (cont'd)

MP3

A compressed audio format. Its small size makes it popular for downloading on internet. MP3 files recorded on CD-R or CD-RW media are suitable for playback on your DVD Player.

NTSC

National Television System Committee. This is the standard system for TV in the USA and Japan, among others.

PAL

Video standard used in most European countries and elsewhere.

Region Code

DVD movies are produced with region encoding to restrict distribution of titles to certain areas at certain times. To play back a DVD title with a specific region code, you will need a DVD player with the same region code.

S-Video

S-Video offers significantly improved video signal performance over a basic composite video connection. To use this type of connection, your TV must have an S-Video input.

VCD

Digital Video Disc. A digital video disc format particularly popular in Asia. Uses MPEG-1 video compression. The picture quality is roughly that of VHS tapes.

Copyright Protection

This product incorporates copyright protection technology that is protected by method claims of certain U.S. Patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works.
© 1992-1997 Dolby Laboratories, Inc. All rights reserved.
All trademarks are the property of their respective owners.

Index

a-b repeat.....	22	pause button.....	7,16
a-b repeat button.....	8	parental lock.....	29
angle button	7	password.....	29
angles (multi-angle playback)	27	play button.....	7,15
arrow buttons	7	power button	7
audio button	7	power cord.....	2,11
audio cd.....	4	power switch	9
audio outputs	11	preview.....	20
audio settings	30	previous button.....	7
back panel	11	prog button	8
batteries	6	program play	23
bookmark button	8	remote control	
bookmarks.....	21	preparing	6
c (clear) button	8	buttons	7-8
coaxial output	11,13	using.....	6
component video output	11,14	repeat buttons	8
composite video output.....	11,12	repeat playback.....	22
connections	11,12-14	reset	
discs	4,5	TV Type.....	31
display button	7	SETUP Factory Defaults	29
display panel	10	return button	8
effect button.....	8	reverse button	7
effects.....	27	safety precautions	2
enter button	7	screen saver.....	16
fast forward button	7	setup button	7
features	4	setup menu	28-32
front panel	9	skip ahead/back	18
glossary.....	35-36	slow button	7
goto	7,19	slow motion playback	18
index.....	37	specifications.....	34
interference	2	standby power.....	15
intro button	8	still picture	16
language settings	32	stop button	7,16
menu button	7	subtitle button.....	8
mp3	4,24	s-video output.....	11,13
mute button	7	table of contents.....	3
next track button.....	7	title button.....	7
number buttons	8	troubleshooting.....	33
open/close button.....	7	video outputs	11
		video settings	31
		zoom button	8
		zoom playback	26